
3-2. Using the air conditioning system and defogger

Front air conditioning system (without touch screen)



Using the automatic mode



The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

STEP 2 Press to switch to automatic air intake mode.

Automatically switches between outside air and recirculated air modes.

STEP 3 Press \wedge to increase the temperature and \vee to decrease the tem-



The temperature for the driver and passenger seats can be set separately.

Adjusting the settings

Adjusting the temperature setting

Press \wedge to increase the temperature and \vee to decrease the tempera-



Press \land (increase) or \lor (decrease) on



to separately adjust the tem-

perature for the passenger and driver sides (dual mode). Press to return the driver and passenger side temperatures to the same setting (simultaneous mode).

The air conditioning system switches between individual and simultaneous modes each time bulk is pressed.


Adjusting the fan speed

Press \land (increase) or \lor (decrease) on $\lor * \land$

Press to turn the fan off.

■ Changing the air outlets





Press MODE .

The air outlets switch each time the button is pressed.

- 1 Air flows to the upper body.
- Air flows to the upper body and feet.
- Air flows to the feet.
- Air flows to the feet and the front windshield defogger operates.
- *: Only in the automatic mode

■ Switching between outside air and recirculated air modes

Press & AUTO & .

The mode switches between (recycles air inside the vehicle), "AUTO" and (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

Defogging the front windshield



1 Press

The air conditioning system control operates automatically.

Recirculated air mode may automatically switch to (outside air) mode.

Pollen removal mode



Press



Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.

Usually the system will turn OFF automatically approximately 3 minutes later.

To stop the operation, press

Adjusting the sensitivity of the air intake control in automatic mode



Press for 2 or more seconds.




Press \land (increase) or \lor (decrease)



From -3 (low) to 3 (high) can be set.


Adjusting the position and opening and closing the air outlets

► Front center outlets




- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Front side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Rear center outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

► Rear side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

■Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur.

- The system may switch automatically to recirculated mode when the coolest temperature setting is selected in summer.
- Immediately after the switch is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

■ Window defogger feature

Recirculated air mode may automatically switch to (outside air) mode in situations where the windows need to be defogged.

■ When outside temperature approaches $32^{\circ}F(0^{\circ}C)$

The air conditioning system may not operate even when _____ is pressed.

Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

■ Pollen removal mode

- When the outside air is cold, the following may occur.
 - Outside air mode does not switch to 🖘.
 - The air conditioning system operates automatically.
 - The operation cancels after 1 minute.
- In rainy weather, the windows may fog up. Press

A CAUTION

■ To prevent the windshield from fogging up

Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.



♠ NOTICE


■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

3-2. Using the air conditioning system and defogger


Front air conditioning system (touch screen without rear air conditioning system)

Airflow and outlets are automatically adjusted according to the temperature setting.



The above illustration is for a vehicle equipped with the navigation system. The position of may differ slightly for vehicles not equipped with the navigation system.

Using the speech command system





You can operate the speech command system. (\rightarrow "Navigation System Owner's Manual")

Using the automatic mode





- The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.
- STEP 2 Press to switch to automatic air intake mode.
 - Automatically switches between outside air and recirculated air modes.
- STEP 3 Press \wedge to increase the temperature and \vee to decrease the tem-

perature on



The temperature for the driver and passenger seats can be set separately.

Adjusting the settings

■ Adjusting the temperature setting

Press \wedge to increase the temperature and \vee to decrease the tempera-



Press \land (increase) or \lor (decrease) on



to separately adjust the tem-

perature for the passenger and driver sides (dual mode). Press to return the driver and passenger side temperatures to the same setting (simultaneous mode).

The air conditioning system switches between dual and simultaneous modes each time vice is pressed.

■ Adjusting the fan speed


Touch any switch of $(decrease \leftrightarrow increase)$ on the operating screen.

Press to turn the fan off.

■ Changing the air outlets



Touch any mode on the operating screen.



- Air flows to the upper body.
- 2 Air flows to the upper body and feet.
- Air flows to the feet.
- Air flows to the feet and the windshield defogger operates.
- *: Only in the automatic mode


■ Switching between outside air and recirculated air modes

Press .

The mode switches between (recycles air inside the vehicle), "AUTO" and (introduces air from outside the vehicle) modes each time the button is pressed.

When the air intake control system is switched to automatic mode, it operates automatically.

Defogging the windshield



Press 💽.

The air conditioning system control operates automatically.

Pollen removal mode



Press 👼.

Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn OFF automatically approximately 3 minutes later.

To stop the operation, press again.



Adjusting the sensitivity of the air intake control in automatic mode


Press until the "Smog Sensor" screen appears while the vehicle is stopped.



Touch any switch of (lower sensitivity ↔ higher sensitivity) on the operating screen.


Adjusting the position and opening and closing the air outlets

► Front center outlets




- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.





- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

Rear center outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

Rear side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

■Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur.

- The system may switch automatically to recirculated mode when the coolest temperature setting is selected in summer.
- Immediately after the switch is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

■ Window defogger feature

Recirculated air mode may automatically switch to (outside air) mode in situations where the windows need to be defogged.

■ When outside temperature approaches $32^{\circ}F(0^{\circ}C)$

The air conditioning system may not operate even when is touched.

■ Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the air conditioning is OFF, and the fan is operating, turning the "AUTO" mode ON will activate the air conditioning system.

■ Pollen removal mode

- When the outside air is cold, the following may occur.

 - The air conditioning system operates automatically.
 - The operation cancels after 1 minute.
- In rainy weather, the windows may fog up. Press

A CAUTION

■ To prevent the windshield from fogging up

Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.

⚠ NOTICE


■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

3-2. Using the air conditioning system and defogger

Front air conditioning system (touch screen with rear air conditioning system)

Airflow and outlets are automatically adjusted according to the temperature setting.



The above illustration is for a vehicle equipped with the navigation system. The position of may differ slightly for vehicles not equipped with the navigation system.

Using the speech command system





You can operate the speech command system. (→ "Navigation System Owner's Manual")

Using the automatic mode





→ The air conditioning system will begin to operate. Air outlets and fan speed are automatically adjusted according to the temperature setting.

"AUTO" will be displayed on the control panel.

STEP 2 Press to switch to automatic air intake mode.

Automatically switches between outside air and recirculated air modes.

STEP 3 Press \wedge to increase the temperature and \vee to decrease the tem-

perature on



Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

Adjusting the settings

Adjusting the temperature setting

Press \wedge to increase the temperature and \vee to decrease the tempera-



The temperature for the driver's, front passenger's and rear seats $(\rightarrow P.$ 228) can be adjusted separately (individual mode). Press (indicator light off) to set the same temperature for all seats (simultaneous mode).

The air conditioning system switches between individual and simultaneous modes each time with is pressed.


In individual mode, the indicator light on comes on.

Adjusting the fan speed

Touch any switch of $(decrease \leftrightarrow increase)$ on the operating screen.

Press to turn the fan off.


■ Changing the air outlets



Touch any mode on the operating screen.

- 1 L: Left-hand front seat
- **2** R: Right-hand front seat

Different air outlets for the lefthand and right-hand front seats can be chosen.



- Air flows to the upper body.
- Air flows to the upper body and feet.
- Air flows to the feet.
- Air flows to the feet and the windshield defogger operates.
- *: Only in the automatic mode

Switching between outside air and recirculated air modes

Press 5 AUTO 80.

The mode switches between (recycles air inside the vehicle), "AUTO" and (introduces air from outside the vehicle) modes each time the button is pressed.


When the air intake control system is switched to automatic mode, it operates automatically.

Using the air purifier

Touch on the operation screen.

The air purifier and rear air conditioning system switches to automatic mode.

Defogging the windshield



Press .

The air conditioning system control operates automatically.

Pollen removal mode



Press 💆

Outside air mode switches to (recirculated air) mode. Pollen is removed from the air and the air flows to the upper part of the body.


Usually the system will turn OFF automatically approximately minutes later.

To stop the operation, press again.



Adjusting the sensitivity of the air intake control in automatic mode


Press until the "Smog Sensor" screen appears while the vehicle is stopped.




Touch any switch of (lower sensitivity ↔ higher sensitivity) on the operating screen.


Adjusting the position and opening and closing the air outlets

► Front center outlets




- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.





- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

► Rear center outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

▶ Rear side outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

■ Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur.

- The system may switch automatically to recirculated mode when the coolest temperature setting is selected in summer.
- Immediately after the switch is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

■ Using the system in recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

■ Window defoager feature

Recirculated air mode may automatically switch to (outside air) mode in situations where the windows need to be defogged.

■ When outside temperature approaches $32^{\circ}F(0^{\circ}C)$

The air conditioning system may not operate even when [77] is touched.

■ Automatic mode for air intake control

In automatic mode, the system detects exhaust gas and other pollutants and automatically switches between outside air and recirculated air modes.

When the air conditioning is OFF, and the fan is operating, turning the "AUTO" mode ON will activate the air conditioning system.

■ Pollen removal mode

- When the outside air is cold, the following may occur.
 - Outside air mode does not switch to
 - The air conditioning system operates automatically.
 - The operation cancels after 1 minute.
- In rainy weather, the windows may fog up. Press



A CAUTION

■ To prevent the windshield from fogging up

Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.



NOTICE


■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

3-2. Using the air conditioning system and defogger Rear air conditioning system (if equipped)

Airflow and outlets are automatically adjusted according to the temperature setting. ► Rear controller (5-seat models) Left side temperature display Off (cooler only) Left side airflow display Fan speed display (cooler only) Automatic mode Right side airflow display Right side temperature display Fan speed Left side Right side temperature control temperature control Changes the left side air outlet used Changes the right side air outlet used


Right side airflow display



Fan speed display

► Front controller (touch screen)

Left side airflow display



Using the automatic mode



The air conditioning system and air purifier will operate, and air outlets and speed will be set automatically.

"AUTO" will be displayed on the control panel.

STEP 2 Press \wedge to increase the temperature and \vee to decrease the tem-



Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

Adjusting the settings

■ Adjusting the temperature setting

Press \wedge to increase the temperature and \vee to decrease the tempera-

ture on

Air outlets and fan speed for the right-hand and left-hand seats may be set separately depending on the temperature setting.

Adjusting the fan speed (air purifier and cooler from the roof vents)


Press \land (increase) or \lor (decrease) on \checkmark

Press off to turn the fan off.

■ Changing the air outlets

Press Auto


The air outlets change as follows each time the button is pressed. Different air outlets for the right-hand and left-hand rear seats can be chosen.



- 11 Air flows to the upper body. *1
- 2 Air flows to the upper body. *2
- Air flows to the upper body and feet.
- 4 Air flows to the feet.
- *: Cooler only
- *1: When the front air conditioning is on.
- *2: When the front air conditioning is off.

Changing the rear seat settings from the front seat

Adjusting the temperature setting



Touch (increase) or (decrease) on the operation screen.

- L: Left-hand rear seat
- 2 R: Right-hand rear seat

The temperature for the right-hand and left-hand rear seats can be adjusted separately (individual mode). Press to set the same temperature for all seats (simultaneous mode).

The air conditioning system switches between individual and simultaneous modes each time is pressed.

In individual mode, the indicator light on comes on.

Adjusting the fan speed (air purifier and cooler from the roof vents)


STEP 1 Touch \rightarrow (\rightarrow P. 220).

STEP 2 Touch any switch of to the operation screen. (decrease ↔ increase)

Press stoturn the fan off.


Adjusting the position and opening and closing the air outlets

► Rear center outlets



- Direct air flow to the left or right, up or down.
- 2 Turn the knob to open or close the vent.

► Rear side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob to open or close the vent.

► Roof side outlets



Direct air flow to the left or right, up or down.

■ Button lock function

► 5-seat models



To prevent inadvertent operation, the buttons on the rear armrest can be locked. Press mode for at least 3 seconds to lock the buttons. Pressing mode again for at least 3 seconds will release the lock.

The indicator appears on the display when the buttons are locked.

► 4-seat models



■ Rear control panel illumination off function

► 5-seat models



Control panel illumination on the rear armrest can be turned off. Press for at least 3 seconds to turn the illumination off. Pressing again for at least 3 seconds will turn the illumination on.

► 4-seat models



■ Replacing the rear air conditioning filter

Replacing the air filter when the use of rear air conditioning or air purification reduces air flow or deodorizing performance (\rightarrow P. 525).

♠ NOTICE

■ To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is off.

3-2. Using the air conditioning system and defogger Rear window and outside rear view mirror defoggers

These features are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

▶ Without touch screen



► With touch screen



ON/OFF

Press the button to turn on the rear window and outside rear view mirror defoggers. The defoggers will automatically turn off after approximately 15 minutes. Pressing the button again also turns the defoggers off.



■ When the outside rear view mirror defoggers are on

Do not touch the outside surface of the rear view mirror, as it can become very hot and burn you.

This feature is used to prevent ice from building up on the windshield and wiper blades.

➤ Without touch screen




ON/OFF

Press the button to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Pressing the button again also turns the de-icer off.

► With touch screen

STEP 1 Press "CLIMATF".



ON/OFF

Touch the switch to turn on the windshield wiper de-icer. The windshield wiper de-icer will automatically turn off after approximately 15 minutes. Touching the switch again also turns the de-icer off.

A CAUTION

■ When the windshield wiper de-icer is on

Do not touch the glass at the lower part of the windshield or to the side of the front pillars as the surfaces can become very hot and burn you.